

## Messing

<b>Hersteller</b>	<b>Art</b>	<b>Bezeichnung</b>
IMN	RM	MG1 - MG6
IMN	RM	WC1 - WC6
IMN	RM	MD1 - MD6
IMN	RM	MF1 - MF6
BNF	RM	C38.01 - C38.06
MBH	RM	TB1 - TB4
IMN	RM	MB1 - MB7
MBH	RM	B1 - B9
ASSO	CRM	M231 - M236
IMN	RM	ME2 - ME5
MBH	RM	B10 - B13
MBH	RM	B14 - B17
MBH	RM	B18 - B20
MBH	RM	B21 - B24
MBH	RM	B25 - B27
BNF	RM	C30.01 - C30.10, C30.12 - C30.14, C30.17, C30.19, C30.21, C30.22, C30.25
BAS	CRM	CURM30.11, CURM30.15, CURM30.16, CURM30.18, CURM30.20
BAS	CRM	CURM30.23, CURM30.24
CTIF	RM	UZ51, UZ52-3, UZ53
CTIF	RM	L1 - L3, L4 - 1, L5, L6, L7 - 1, L20 - L23
CTIF	RM	LH1, LH2, LH5, LH6-1, LH7-1A, LH10 - LH13
CTIF	RM	UZHR4, UZHR7, UZHR9
BAM	RM	368
BAS	CRM	CURM43.01
BNF	RM	C43.02, C43.03
NIST	CRM	1107, 1108
IMN	CRM	WK1 - WK5
BAS	CRM	CURM42.21 - CURM42.25
Brammer	RM	464A, 482A
MBH	RM	NB1 - NB4
IMN	CRM	MH1 - MH5
BAS	CRM	CURM48.01 - CURM48.05
NIST	CRM	1110, 1111
ASSO	CRM	4337-88 bis 4341-88
ASSO	CRM	6356-92 bis 6369-92
IMN	CRM	WF1 - WF6
MBH	RM	MNB1 - MNB6
MBH	RM	WSB1 - WSB6

CTIF	RM	LS1
IMN	CRM	WH1 - WH5
IMN	RM	WM1 - WM5
Panenske Brezany	RM	MS1, MS2, MS5 - MS10
NIST	CRM	1104
IMN	CRM	WN1 - WN5
Brammer	RM	360A
IMN	RM	WG1 - WG6
ASSO	CRM	6319-92 - 6323 - 92
MBH	RM	7835.1 - 7835.4
ASSO	CRM	M2151 - 2158
Brammer	RM	675, 675A, 857A, 863A, CC8571, 314B
Claxton	RM	314, 673, 675, 857, 863